

进口摇头开关现货stock, 日本钮子开关PDF说明书 样本
进口钮子开关toggle switches选型资料 推荐型号:

型号 电路 功能 电气参数

PARTS NO. CIRCUIT SWITCHING FUNCTION RATING

* MS-500K, SPST, OFF-ON 6A.125V.AC
* MS-500A, SPDT, ON-ON 6A.125V.AC
* MS-500B, SPDT, ON-(ON) 6A.125V.AC
* MS-500C, SPDT, ON-OFF-ON 6A.125V.AC
* MS-500D, SPDT, ON-OFF-(ON) 6A.125V.AC
* MS-500E, SPDT, (ON)-OFF-(ON) 6A.125V.AC
* MS-500F, DPDT, ON-ON 6A.125V.AC
* MS-500G, DPDT, ON-(ON) 6A.125V.AC
* MS-500H, DPDT, ON-OFF-ON 6A.125V.AC
* MS-500I, DPDT, ON-OFF-(ON) 6A.125V.AC
* MS-500J, DPDT, (ON)-OFF-(ON) 6A.125V.AC
* MS-500K-B, SPST, OFF-ON 6A.125V.AC
* MS-500A-B, SPDT, ON-ON 6A.125V.AC
* MS-500B-B, SPDT, ON-(ON) 6A.125V.AC
* MS-500C-B, SPDT, ON-OFF-ON 6A.125V.AC
* MS-500D-B, SPDT, ON-OFF-(ON) 6A.125V.AC
* MS-500E-B, SPDT, (ON)-OFF-(ON) 6A.125V.AC
* MS-500F-B, DPDT, ON-ON 6A.125V.AC
* MS-500G-B, DPDT, ON-(ON) 6A.125V.AC
* MS-500H-B, DPDT, ON-OFF-ON 6A.125V.AC
* MS-500I-B, DPDT, ON-OFF-(ON) 6A.125V.AC
* MS-500J-B, DPDT, (ON)-OFF-(ON) 6A.125V.AC
MS-500K-BC, MS-500A-BC, MS-500B-BC, MS-500C-BC,
MS-500D-BC, MS-500E-BC, MS-500F-BC, MS-500G-BC,
MS-500H-BC, MS-500I-BC, MS-500J-BC,
MS-500K-F, MS-500A-F, MS-500B-F,
MS-500C-F, MS-500D-F, MS-500E-F,
MS-500F-F, MS-500G-F, MS-500H-F,
MS-500I-F, MS-500J-F,
MS-500K-MF, MS-500A-MF, MS-500B-MF,
MS-500C-MF, MS-500D-MF, MS-500E-MF,
MS-500F-MF, MS-500G-MF, MS-500H-MF,
MS-500I-MF, MS-500J-MF,
MS-500K-B2, MS-500A-B2, MS-500B-B2,
MS-500C-B2, MS-500D-B2, MS-500E-B2,
MS-500F-B2, MS-500G-B2, MS-500H-B2,
MS-500I-B2, MS-500J-B2,
MS-500K-B-PC, MS-500A-B-PC, MS-500B-B-PC,
MS-500C-B-PC, MS-500D-B-PC, MS-500E-B-PC,
MS-500F-B-PC, MS-500G-B-PC, MS-500H-B-PC,

在线查询进口开关 www.omrons.com.cn 全国统一热线4006-022-002
010-68008 911北京 www.shuntu.net 0755-83656701 深圳

MS-500I-B-PC, MS-500J-B-PC,

MS-500K-B-RI, MS-500A-B-RI, MS-500B-B-RI,
MS-500C-B-RI, MS-500D-B-RI, MS-500E-B-RI,
MS-500F-B-RI, MS-500G-B-RI, MS-500H-B-RI,
MS-500I-B-RI, MS-500J-B-RI,
MS-500K-B-VT, MS-500A-B-VT, MS-500B-B-VT,
MS-500C-B-VT, MS-500D-B-VT, MS-500E-B-VT,
MS-500F-B-VT, MS-500G-B-VT, MS-500H-B-VT,
MS-500I-B-VT, MS-500J-B-VT,
MS-500K-LL-S, MS-500A-LL-S, MS-500C-LL-S,
MS-500F-LL-S, MS-500H-LL-S,
MS-500K-LL-P, MS-500A-LL-P, MS-500C-LL-P,
MS-500F-LL-P, MS-500H-LL-P,
MS-500A-B-PCB, MS-500B-B-PCB,
MS-500C-B-PCB, MS-500D-B-PCB, MS-500E-B-PCB,
MS-500F-B-PCB, MS-500G-B-PCB, MS-500H-B-PCB,
MS-500I-B-PCB, MS-500J-B-PCB,
MS-500A-B-PS, MS-500B-B-PS,
MS-500C-B-PS, MS-500D-B-PS, MS-500E-B-PS,
MS-500F-B-PS, MS-500G-B-PS, MS-500H-B-PS,
MS-500I-B-PS, MS-500J-B-PS,
MS-500K-CL, MS-500A-CL, MS-500B-CL,
MS-500C-CL, MS-500D-CL, MS-500E-CL,
MS-500F-CL, MS-500G-CL, MS-500H-CL,
MS-500I-CL, MS-500J-CL,
MS-500K-ML, MS-500A-ML, MS-500B-ML,
MS-500C-ML, MS-500D-ML, MS-500E-ML,
MS-500F-ML, MS-500G-ML, MS-500H-ML,
MS-500I-ML, MS-500J-ML,
MS-500K-PL, MS-500A-PL, MS-500B-PL,
MS-500C-PL, MS-500D-PL, MS-500E-PL,
MS-500F-PL, MS-500G-PL, MS-500H-PL,
MS-500I-PL, MS-500J-PL,
MS-500M-B, 3PDT, ON-ON 6A.125V.AC
MS-500N-B, 3PDT, ON-OFF-ON 6A.125V.AC
MS-500P-B, 4PDT, ON-ON 6A.125V.AC
MS-500R-B, 4PDT, ON-OFF-ON 6A.125V.AC